

This exploded view diagram illustrates the assembly of the ECU. The components are numbered as follows:

- ①: ECU main body (cubic housing with a logo).
- ②: ECU mounting bracket (a complex bracket with multiple mounting points).
- ③: ECU mounting plate (a square plate with four mounting holes).
- ④: ECU mounting nut (a large nut with a flange).
- ⑤: ECU mounting washer (a flat washer).
- ⑥: ECU mounting cap (a cap with a flange).
- ⑦: ECU mounting screw (a long screw with a hex head).